

SL-15 User Manual

Thank you for choosing our product. For safe and optimal use of the watch, please, read this guide carefully.

1. Contents

| | |
|--|----|
| 1. Contents..... | 1 |
| 2. Warnings and safety instructions..... | 2 |
| 3. Before you begin | 3 |
| 4. Charging the watch | 4 |
| 5. Operation..... | 5 |
| 5.1 Display | 5 |
| 5.2 Buttons | 5 |
| 6 Operating the watch | 6 |
| 6.1 Powering on | 6 |
| 6.2 Phone calls | 7 |
| 6.2.1 Making a call | 7 |
| 6.2.2 Answering a call | 8 |
| 6.2.3 Declining a call | 8 |
| 6.2.4 SOS call | 8 |
| 6.3 Cancelling the current operation | 8 |
| 6.4 Powering off the watch | 9 |
| 7 FAQ | 9 |
| 7.1 I cannot turn on the watch | 9 |
| 7.2 What operation systems is the mobile application compatible with?..... | 9 |
| 7.3 Some mobile numbers cannot call the watch. Why is that? | 10 |
| 7.4 How can I turn off the watch? | 10 |

2. Warnings and safety instructions

- Please, do NOT take out the SIM card when the watch is powered on. It could cause damage to the watch.
- Please, do NOT immerse the watch under water. The watch comes with IP66 water protection, which will protect it even from strong water jets but not from underwater pressure.
- Please do NOT take into a shower or bath. This will damage the device and will void warranty.
- Please, make sure the SIM card slot cover is properly closed to avoid water entering the watch. This will void warranty.
- Keep the product away from fire and avoid high temperature environments.
- The watch cannot send location information when the battery has run out, there is no mobile data service (no E symbol on the watch display) or the watch is out of the GSM network coverage area.
- When there is no data service, the watch cannot be located on the map.
- While roaming within North America (U.S and Canada) is free, international roaming has a rate of \$15/MB and is disabled. Please contact us to enable international roaming if needed.

3. Before you begin

- Make sure the watch is fully charged before you begin. It is recommended to charge the watch for at least 12 hours before the first use.
- The watch operates with a quad band 2G GSM chip (850/900/1800/1900 MHz). It is recommended that you ensure there is a good coverage of 2G GSM in your area.

4. Charging the watch

Remove the watch and the charging cable from the packaging. Connect the magnetic head of the cable to the metallic contacts on the back of the watch (rotate the connector until the magnets pull it in position) and connect the other end of the cable to a USB power source.



Charging the watch to its full capacity normally takes 2-3 hours. However, for the first time, please, charge the watch for 12 hours and 8 hours for the second and third times to ensure a long battery life. It is highly recommended to use a good quality adapter for charging the watch. Please, do NOT turn on the watch yet. You need to install the mobile application first as described in the next chapter.

5. Operation

Below you will find the description and operation of the watch.

5.1 Display

Besides the date and time, the watch displays other information: the GSM signal strength and the data connection status (E), the number of steps collected by the built-in pedometer and the battery status.



5.2 Buttons


For phone calls and voice messages, the speaker is above the screen and the microphone is between two buttons on the right. The functions of the 4 buttons are as follows:

Button 1: Voice messages (not implemented yet)

Button 2: SOS calls / Answer calls / Hang up calls

Button 3: Outgoing phone calls (select number and initiate call)

Button 4: Power / Hang up / Exit



6. Operating the watch

With the mobile application installed and set up, now you can start using the watch. Please, follow the steps below.

6.1 Powering on

Press and hold **Button 4** for 3 seconds to power on the watch. “SafeLink GPS” appears on the screen and a chime is played. The watch shows the date and time. Wait until it connects to the GSM network,  appears in the top left corner of the watch display.

Soon after,  should also appear. This shows that the data connection is ready. This is necessary to track the watch.

Note: If  the symbol does not appear shortly after the symbol when you use the watch for the first time, the watch may not support your telecom operator. If it disappears during normal operation, you might have run out of your data package or the coverage is not enough for data transfer.

6.2 Phone calls

One of the basic functions of the watch is to initiate and receive phone calls to and from the phone numbers enabled in the mobile app.

6.2.1 Making a call

To call the administrator of the watch, press and hold **Button 3** for 3 seconds. The call will start automatically without entering or selecting the phone number.

To call other numbers in the Family list, press **Button 3** repeatedly until you see the name and phone number you want to call. Now press and hold **Button 3** again to make the call.

When the call is finished, press **Button 2** or **Button 4** to hang up. To exit the Family list, press **Button 4** any time.

6.2.2 Answering a call

To answer an incoming call, you can press any of the buttons on the right (**Button 1**, **Button 2** or **Button 3**.)

6.2.3 Declining a call

There are two ways to decline a call. Press **Button 4** on the left or Press **Button 2** twice.

6.2.4 SOS call

In case of an emergency, you can use the SOS call function to reach family members. Turn on the display, press and hold **Button 2** for 3 seconds. The watch will call the first 4 preset numbers one by one starting with the administrator and repeats it until one of them answers the call or it has called these numbers 3 times each.

6.3 Cancelling the current operation

When the watch display shows any of the menus or lists, press **Button 4** to return to the normal display.

When making phone calls (including SOS calls), press **Button 2** or **Button 4** to cancel the call and return to the normal display.

6.4 Powering off the watch

If there is no SIM card in the watch: press and hold **Button 4** to turn off the watch. A chime will be played and the TAKIT logo appears on the display.

When there is a SIM card in the watch: for safety reasons, the watch can only be turned off remotely. Open Watch Settings in the APP and look for the **Remote watch turn off** function.

Note: only the administrator can turn off the watch from the APP.

7. FAQ

7.1 I cannot turn on the watch

The battery in your watch might have run out of power. Please, connect the watch to a power source until fully charged and then try again.

7.2 What operation systems/Browser is compatible with the web based tracking application?

Any modern browsers under any operating systems. For example: PC, tablets, smartphones etc.

7.3 Some mobile numbers cannot call the watch. Why is that?

Only numbers entered in the Family list in the mobile app can successfully call the watch. All other numbers are blocked.

7.4 How can I turn off the watch?

If there is no SIM card in the watch: press and hold **Button 4** to turn off the watch. A chime is played and the “SafeLink GPS” logo appears on the display.

When there is a SIM card in the watch: for safety reasons, the watch can only be turned off remotely.